

## Fixing instructions Fradiflex expansion joint connection



1 Unpack expansion joint connection



2 Unscrew wing nuts



3 Take off pressure plate



4 Remove protective film



5 Position the expansion joint connector on the expansion joint waterbar and mark the required drill hole positions.



6 Drill the required holes into the expansion joint waterbar using a drill with a DN 6 mm bit.

Alternatively the holes can be punched using a belt punch.

>>>

## Fixing instructions Fradiflex expansion joint connection



7 Push threaded bolts through the expansion joint waterbar so that the waterbar is directly connected to the expanding water stop (red).



8 Place pressure plate in position onto the threaded bolts and tighten the wing nuts securely. For heavily profiled expansion joint waterbars it may be necessary to smoothen (cut) the profile in the area abutting the expanding water stop.



9 Remove the protective film from the special coating on the Fradiflex and press against the expansion joint connection.